

---

# Smallogger II

---

[Audio Server](#)

---

[Firmware update guide](#)

## FIRMWARE UPDATE

You can update the audioserver firmware. We recommend regular checking of updates on our site

<http://www.speechpro.ru/support/download>.

To update audioserver firmware, select the **Firmware** point on page **Settings** in section **Settings groups** (Figure 1), then click **Browse...** and select a file with firmware update, click **Upload**.




Figure 1. Firmware updating

Updating process will be displayed as a progress bar (Figure 2).




Figure 2. Firmware updating process

After the completion of the update, you will need to re-login.



During software updating, audioserver automatically disconnects from the network, so any attempts to enter audioserver at this time will be unsuccessful.



Do not turn off audioserver power supply during the updating process– this will result in its inoperability.



We recommend pressing **Ctrl+F5** on the each audioserver's page after updating, in order to clear browser's cache.